



INSTALLATION

GUIDE FOR ELECTRIC BLINDS



skylights1.co.uk

STEP-BY-STEP INSTALLATION GUIDE

1. Position the blind up the recess and hold it where you would like it to be fixed, please allow 150mm to 200mm from the glazing for ventilation.
2. The wire coming out of the blind should be facing the glazing.
3. Mark the holes on the wall through the pre-drilled holes with a pencil.



STEP-BY-STEP INSTALLATION GUIDE

4. Drill the holes on the wall and insert appropriate rawlplugs.

5. Position the blind back in place and fix it through the previously drilled holes.

Wire connections to be made by a professional.

6. Use the trims provided around the blind to cover the gap left between the wall and the blind.

Use the cleaning wipe provided to clean the surface where the double sided tape will be applied and allow it to dry.

Use the primer to prime the area where the double sided tape will be applied.

Apply the trims.





CONTACT US



[skylights1.co.uk](https://www.skylights1.co.uk)



020 8396 6979



4 East Street, Crowland,
Peterborough, England,
PE6 0EN

